

# ***INSTALLATION PREP GUIDE***

This guide will help you know what to expect when MCS installs your signage, along with some helpful tips and steps you can take to prepare for installation.

## **WE WILL -**

Measure, confirm installation location and design before the installation process begins. Our experienced team will bring all the necessary tools to complete the installation. We always wipe down and prep the space beforehand.

## **WE ASK -**

When installing large wall coverings we ask that all objects near the desired wall are moved away from the area. If possible, please remove outlet covers or any frames, coverings that may be in the way of the final graphic.

MCS may use a heat gun to complete the installation and may need to access a nearby outlet if available.

For perforated window clings, please clean the windows with water prior to our arrival. If you are unable to do so, MCS will prep the windows before installation.

## **SOME THINGS TO KEEP IN MIND -**

Perforated window clings can only be installed in temperatures 50 degrees or higher. This ensures the vinyl adheres properly and lasts longer.

Other exterior vinyl may be applied in slightly colder weather using a cold weather fluid. This depends on the location of the vinyl and weather conditions.

